Colin's Sash Windows

Delivered Nationwide, Trade and Retail

OVER 50,000 WINDOWS SUPPLIED SINCE 2014

Building Regulation Part O: Overheating Comprehensive Technical Guide

1. Introduction

Part O of the Building Regulations was introduced to prevent overheating in new residential buildings. It represents a major shift in how modern homes must be designed, with a new focus on solar gain, ventilation performance, glazing selection, and environmental constraints such as noise exposure, security requirements, and urban heat.

2. Scope of Part O

Part O applies to: • New-build residential dwellings • New dwellings formed through material change of use • Student accommodation • Care homes and other institutional residences It does not apply to extensions or refurbishments unless they create new dwellings.

3. Overheating Risks Considered by Part O

The regulation identifies several key overheating drivers: • Solar gains through large or poorly oriented glazing • Insufficient night ventilation • Urban heat island effect • Reduced natural ventilation due to noise or safety concerns • Internal heat gains from occupants and appliances

4. Limiting Solar Gains

Part O requires designers to limit unwanted heat entering the building. Measures include: • Reducing window areas on south- and west-facing elevations • Using low-g or solar-control glass with low SHGC values • External shading devices such as overhangs, shutters or brise-soleil • Internal layouts where high-gain rooms are shaded • Avoiding excessive floor-to-ceiling glazing in high-risk zones

5. Means of Removing Excess Heat

Homes must be capable of removing heat effectively, especially during summer nights. There are three methods: A. Natural Ventilation Requires windows to provide specific free-area openings, measured in mm^2. Trickle vents do not count toward free-area. B. Cross-Ventilation Required in many high-risk areas. Opposing windows or openings must allow airflow to pass across the dwelling. C. Mechanical Systems Used only if natural ventilation cannot achieve compliance. Includes: • MVHR systems • MEV systems • Mechanical cooling (air-conditioning) – only as a last

resort

6. Free-Area Window Requirements

Free-area refers to the unobstructed opening area of a window, not the sash size. Requirements vary by: • Risk zone (standard vs high-risk regions) • Room type • Window configuration (side-hung, top-hung, tilt & turn) In high-risk areas such as London, larger openings or cross-vented layouts are typically mandatory.

7. Interaction with Noise Regulations

In high-noise environments (busy roads, rail, airports), openable windows may be restricted at night. When night cooling cannot rely on open windows, alternative solutions must be installed, such as: • Enhanced mechanical ventilation • Acoustic louvres • Mechanical cooling systems

8. Security & Safety Constraints

Part O does not override other regulations. Designers must still comply with: • PAS 24 security • Approved Document Q (security) • Approved Document K (fall protection) Windows may require restrictors or secure night-vent positions, provided they still achieve free-area targets.

9. Glazing Specifications Under Part O

Solar-control glass is frequently recommended. Consider: • G-value (lower is better for limiting gain) • U-value (balance with thermal performance) • Light transmission (too low may cause daylight issues) Architects often pair solar-control glass with reduced glazing areas on problematic elevations.

10. Cross-Ventilation Design Principles

Cross-ventilation significantly improves purge airflow. To comply: • Rooms must have openings on opposite or adjacent external walls • Internal doors must allow flow (gap under door or ventilation grille) • Internal partitions must not block airflow

11. Mechanical Cooling Allowance

Mechanical cooling can only be used if: • All passive and natural ventilation methods fail • The overheating assessment proves it is necessary • The system is sized for comfort only • It does not encourage excessive energy use

12. Required Overheating Assessment Documentation

Building Control requires: • Dynamic thermal modelling OR simplified Part O method • Detailed glazing schedule • Free-area calculations for all windows • Ventilation strategy • Shading and solar gain reduction design

13. Typical Part O Design Changes Seen in Practice

• Smaller glazing areas in south- and west-facing rooms • More side-hung casement designs • Increased use of dual-functional or tilt-and-turn windows • Higher demand for solar-control glazing • Additional mechanical ventilation requests in noisy urban areas

14. Regional Differences

High-risk overheating areas include: • London • Greater London Urban Heat Zones • Parts of Kent, Essex, Hertfordshire, Surrey These regions require stricter controls on glazing and ventilation.

15. Summary

Part O is now a critical design driver in residential construction. It increases scrutiny on window sizing, opening types, ventilation strategy, glazing specification and shading solutions. The overarching goal remains simple: **Create homes that remain safe and comfortable during hot weather without unnecessary energy use.**